

Ford Transit 2.4TCI 90HP 2004

1. Find plug on the fuel injection pump. Disconnect it and connect box adapter between.

