

Mercedes E 300TD

ECU connector:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	
38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	

Connections:

ECU pin no.	Function	Wire color in box harness
55	Power +12V	Red
4	Ground	Black
9	Signal 1	Yellow
46	Signal 2	Blue
22	MAP sensor signal	White